TEXAS TIMERS SUPERIOR PRODUCTS FOR FREE FLIGHT MODELS

www.TexasTimers.com 3317 Pine Timbers Drive Johnson City, TN 37604 USA

TEXAS TIMERS e MAX QUICK START GUIDE rev 6-6-14

- Connect ESC, Servo, and Battery
- Set switches for Motor and DT time. Refer to handy time setting chart. It is not possible to set DT time for less than the Motor run. (well you can set it, but the motor will not start)
- You will note the LED is flashing at a 10 second rate to let you know that power is on and the timer is ready for action.
- Press the button one time and the LED is blinking rapidly, advising you that the timer is armed.
- Press and hold the button and after two (2) seconds the motor will start. (The delay is a safety factor) The motor may be stopped by releasing the button and pressing it one time. It returns to the idle mode. The LED will remain on as long as the motor is running as a visual aid to confirm timing on the ground.
- Launch the plane and as you release the button the timer automatically starts.
- Retrieve and Repeat. Change Motor or DT times as desired. Can be changed anytime up to launch and button release.
- Remember to remove battery power when done flying. Do not leave it connected as it will totally deplete and ruin your LiPo battery. This is why we flash the LED as a notice that power in on.

ENJOY